

Thank you for purchasing the **Swing Arm Wall Sconce**. This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

For safe mounting, it is essential to use wall anchors appropriate to your wall type (i.e. plaster, drywall, concrete, etc.). Mount to wood studs whenever possible. These instructions are for drywall mounting only.

hardware



4 - plastic anchors 4 - studs 4 - caps


Missing hardware?
Please call **800.606.6387** for replacements.

tools required



level phillips head screwdriver


components




1 - 13 watt max CFL bulb (INCLUDED)
OR 60 watt max type A standard bulb (NOT INCLUDED)

1 - wall sconce assembly


NOTE: If you are unsure about your wall type or what mounting method you should use, consult a qualified professional or your local hardware store.




1 Determine the location for the wall sconce. Using a **level**, position **wall sconce assembly** and mark 4 hole positions on the wall. Set wall sconce assembly aside. Drill a pilot hole in the wall stud. If the wall stud is not available, drill a hole in the wall that is slightly smaller in diameter than the anchor. Insert 4 **plastic anchors** into holes. Gently tap **plastic anchors** into the wall until the flange of the anchor is flush.



2 Insert 1 **stud** into each **plastic anchor** as shown, and secure using a **phillips head screwdriver**.



3 Fit back plate of assembly over studs in wall. Secure studs to assembly with 4 caps.



4 Insert 1- **bulb (included)** into socket. DO NOT EXCEED SPECIFIED WATTAGE. Installation is now complete.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to override this safety feature.

cleaning & care

Do not use polishes or cleaners on your lamp. Dust surfaces with a dry soft cloth. The matte black finish is prone to scratch more easily than other finishes, please take care when handling.