


Thank you for purchasing the **Bobby Dining Table**. This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage. Note: 2 people are required to safely assemble this product.

hardware



4 - pads




20 - bolts


Missing hardware?

Please call **800.606.6387** for replacements.

components




1 - tabletop




4 - legs

tools required



allen wrench (included)



A. With the assistance of another adult, place **tabletop** upside down onto a clean, padded surface. Attach each **leg** to tabletop with **5 bolts**, using an **allen wrench**. Do not over tighten the bolts.
 B. Adhere 1 **pad** to each **leg** as shown. With the assistance of another adult, position unit upright.

Assembly is now complete.

cleaning & care

Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Do not use furniture wax or polish as the unit is finished with a protective clear lacquer. It is recommended to use coasters to protect surface from heat and water.