



### hardware



4 - cams



4 - cam screws




8 - wood dowels



4 - shelf pins




4 - cam covers



4 - bolts

Missing hardware?  
Please call **800.606.6387** for replacements.


### tools required




Phillips head screwdriver

(We recommend the use of hand tools instead of power tools)


### components




1 - bottom panel




1 - top panel



1 - back panel




1 - shelf



2 - side panels  
(1 right, 1 left)

**NOTE:** Do not over tighten cam screws.



Place **top panel** onto a clean, padded surface. Insert 4 **cam screws** as shown. Secure, but do not over tighten screws with a **Phillips head screwdriver**.

**1**

NOTE: Make sure arrows on each cam points toward nearest edge with holes

left side panel

right side panel

A

B

2

A) Insert 2 **cams** into each **side panel**, making sure arrow on cam points towards the nearest edge with holes.

B) Insert 4 **wood dowels** into each side panel as shown.

right side panel

left side panel

A

B

3

A) Fit dowels of **right and left side panels** into corresponding holes of **top panel** as shown.

B) Secure assembly by turning each **cam** clockwise with a screwdriver until each cam securely engages each cam screw.

back panel


4

Align edge of **back panel** with grooves in side and top panels and slide into position as shown.

bottom panel

5

Position **bottom panel** as shown and fit onto dowels of assembly. Attach with 4 **bolts** and secure with a screwdriver.



- 6**
- A) With assistance of another adult, turn assembled unit upright. Insert 4 **shelf pins** into side panels as shown.
  - B) Place **shelf** onto shelf pins, making sure to fit notches of shelf securely onto pins.
  - C) Cover all exposed cams with **cam covers**.
- Assembly is now complete.

## cleaning & care

Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners.