


Thank you for purchasing the **Beale Lounge Chair**. This page lists all the contents included in the box. Please take time to identify the hardware as well as the individual components of this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

## hardware



4 - bolts



4 - flat washers




4 - spring washers

Missing hardware? Please call **800.606.6387** for replacements.


## components



1 - seat




1 - leg frame



1 - cushion

## tools required

allen wrench (included)




(We recommend the use of hand tools instead of power tools)

## assembly

Position **seat** as shown. Align screw holes of **leg frame** with **seat**. Make sure the arrow is pointed toward the front of the chair as shown. Attach **leg frame** to bottom of seat with 4 **bolts**, 4 **spring washers** and 4 **flat washers**. Secure, but do not over tighten bolts with an **allen wrench**. Position unit upright.

Assembly is now complete.



## cleaning & care

Dust with a soft dry cloth. Cushion cover is removable and may be dry cleaned.