

Thank you for purchasing the **Charlie Barstool**. This page lists all the contents included in the box. Please take time to identify the hardware as well as the individual components of this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


hardware




4 - bolts

Missing hardware?
Please call **800.606.6387** for replacements.

components




1 - seat



1 - leg frame

tools required



allen wrench (included)

assembly


A) Place **seat** upside down as shown. Align holes in **leg frame** over holes in bottom of seat, making sure arrow label points forward as shown.

B) Loosely insert **4 bolts** through holes in leg frame into seat.

C) Make any necessary adjustments to the seat and frame position and then fully tighten all 4 bolts with the **allen wrench**.

Turn the chair over.

Assembly is now complete.



NOTE: Make sure arrow label faces forward as shown.

cleaning & care

Clean only by vacuuming or light brushing to remove soil. Never use water, foam or liquid cleaning agents. Professional upholstery cleaning is recommended. Periodically re-tighten bolts.