






hardware



16 - hex nuts



16 - washers





16 - bolts

Missing hardware?
Please call **800.606.6387** for replacements.


tools required

allen wrench (included)


hex wrench (included)


components



2 - leg frames
(1 - labeled A,
1 - labeled B)



1 - tabletop



4 - brackets

STEP 1: With the assistance of another adult, position **tabletop** upside down onto a clean, padded surface. Loosely attach each **leg frame** to **tabletop** with 4 **hex nuts**, 4 **washers** and 4 **bolts**.


STEP 2: Loosely attach each **bracket** to **leg frame** and **tabletop** with 2 **hex nuts**, 2 **washers** and 2 **bolts**.

At this point, fully tighten all **hex nuts** with a **hex wrench** and all **bolts** with an **allen wrench**. Position unit upright. Assembly is now complete.

NOTE: Do not over tighten the bolts.

NOTE: Make sure leg frames marked A/B corresponds with tabletop marked A/B

NOTE: Make sure brackets of each leg are positioned outside during assembly



cleaning & care

Clean surfaces with a dry soft cloth. Do not use abrasive cleaners. Placemats and coasters must be used to protect from scratches, heat and water.