




Thank you for purchasing the **Ergo Drink Table**. This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


**hardware**



4 - bolts    4 - washers    1 - threaded connector    4 - adhesive pads

Missing hardware?  
Please call **800.606.6387** for replacements.


**tools required**




allen wrench

Note: We recommend the use of hand tools instead of power tools.


**components**




1 - tabletop



1 - leg base




1 - center pole



**1**

Place **tabletop** face down on clean, padded surface as shown. Attach **center pole** with 4 **bolts** and 4 **washers**. Secure using an **allen wrench** as shown.



- A. Secure **threaded connector** into the **center pole** as shown.
- B. Secure **leg base** by turning clockwise until leg base and center pole meet.
- C. Attach 4 **adhesive pads** to the bottom of the leg base as shown.

Position unit upright. Assembly is now complete.

### cleaning & care

Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Do not use furniture wax or polish as the unit is finished with a protective clear lacquer. It is recommended to use coasters to protect surface from heat and water.

2