


## thank you

Thank you for purchasing the **Fresh Ink Clock**. This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

## tools required



phillips head screwdriver

(We recommend the use of hand tools instead of power tools)

## battery requirement

3 - AA/1.5V batteries  
(not included)

## care and cleaning


Clean surfaces with a dry or damp soft cloth.  
Do not use abrasive cleaners.

For better performance:

- Do not mix battery types
- Do not mix old and new batteries
- Remove batteries if the clock is not in use
- Do not attempt to recharge non-rechargeable batteries
- Remove exhausted batteries immediately
- Keep these instructions for future reference


**PLEASE REFER TO BATTERY PACKAGING FOR PROPER DISPOSAL OF BATTERIES**

## installation




**A**

A. Using a **phillips head screwdriver**, remove **battery cover** from back of **clock** as shown. Set cover and hardware aside until further instructions.



**B**

B. Install **3 AA/1.5V batteries (not included)** according the polarity as indicated on the battery case.



**C**

C. Adjust **dial** to set time. Replace **battery cover** to back of **clock**.