

Thank you for purchasing the **Oiseau Floor Lamp**. This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

## hardware




1 - hex nut



1 - lock washer

Missing hardware?  
Please call **800.606.6387** for replacements.

## tools required




hex wrench  
(included)

## cleaning & care

Do not use polishes or cleaners on your lamp. Dust surfaces with a dry soft cloth.


## components



1 - socket assembly

1 - top upright

1 - bottom upright



1 - base


A. Attach **socket assembly** to **top upright**. Turn top upright as shown to secure.

B. Attach **top upright** to **bottom tube**. Turn bottom upright as shown to secure.

C. Attach **base** to lamp assembly. Fit threaded stud of upright through **base** and secure with 1 **lock washer** and 1 **hex nut**, using a **hex wrench**.

Assembly is now complete.

NOTE: Make sure base is securely tightened facing front and cord faces back as shown



1