

Thank you for purchasing the **Sawyer Ottoman**. This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage. Note: 2 people are required to safely assemble this product.


hardware



10 - bolts


Missing hardware?
Please call **800.606.6387** for replacements.

tools required




allen wrench (included)


components




1 - front panel




1 - back panel



2 - leg frames
(1 left, 1 right)





1 - top panel



1

Attach **left leg frame** to **front and back panels** with 3 **bolts** as shown. Secure, but do not over tighten, bolts using an **allen wrench**.



cleaning & care

-During normal weathering, wood may crack slightly due to changes in moisture. This does not affect the structural integrity of your furniture.

-Clean surfaces with a dry or damp soft cloth.

-Do not use abrasive cleaners. We recommend the use of outdoor furniture cleaner that can be purchased at Crate and Barrel. This cleaner should be used before teak oil application.

-As wood is a natural material, its appearance may change if left outside and untreated. A teak oil surface coating is vital in protecting it from premature lightening, or splitting, when exposed to weather. We recommend the finish be regularly maintained to ensure that the wood is protected from moisture and the furniture continues to look its best.

-In order to maintain the appearance of the wood, regular coatings of teak oil should be applied every two months. The frequency will depend on the weather conditions experienced.

-To prolong the life of this wooden furniture, it should be protected from severe weather and stored under cover during winter. A liberal coating of teak oil should be given to the furniture before it is stored, and again when it is removed from storage.

-Should you choose not to treat your furniture, then it will fade and turn a lighter color and develop cracks. Light sanding can refresh the color. After sanding, teak oil can be regularly applied in accordance with the instructions above.

-Store in a cool, dry place after ensuring it is clean and dry.