



This page lists the contents included in the box. Please take time to identify the hardware as well as the individual components of the product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage. Please follow the assembly instructions closely. Improper assembly can result in personal or property damage.



## hardware & components



800.606.6387



3 - 13 watt max CFL dimmable bulbs (INCLUDED)

OR

3 - 60 watt max type A standard bulbs (NOT INCLUDED)




1 - felt pad

## cleaning & care

Dust surfaces with a dry soft cloth. Do not use cleaners or polishes on the lamp.

## important safety instructions

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to override this safety feature.



A. Attach **middle tube** to **shade assembly**. Turn middle tube counter clockwise as shown to secure.

B. Attach **bottom tube** to **middle tube**. Turn bottom tube counter clockwise as shown to secure.

C. Attach **bottom tube** to **base**. Turn bottom tube clockwise as shown to secure.

D. Remove backer from **felt pad** and attach to underside of base.

E. Insert 3 bulbs into shades. **DO NOT EXCEED SPECIFIED WATTAGE.**