signal FLOOR LAMP



Thank you for purchasing the **Signal Floor Lamp.** This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

hardware

9 - washers

9 - screw caps

Missing hardware?
Please call **800.606.6387** for replacements.

IMPORTANT SAFETY INSTRUCTIONS:
This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to override this safety feature.

components

3 - 13 watt max CFL bulbs
(INCLUDED)
OR
3- 60 watt max type A standard bulbs
(NOT INCLUDED)

3 - diffusers



1 - lampshade assembly

1 - base assembly

With the assistance of another adult, attach **lampshade assembly** to **base assembly** as shown. Turn **lampshade assembly** clockwise to secure.



1

A. Carefully tilt **lampshade assembly** back as shown. Insert 3 **bulbs** (included) into corresponding sockets of each lampshade.
B. Attach 3 **diffusers** to **lampshade assembly** with 3 **washers** and 3 **screw caps** per diffuser. Turn screw cap clockwise to secure.
Assembly is now complete.



2

cleaning & care

Do not use polishes or cleaners on your lamp. Dust surfaces with a dry soft cloth.