sphera FLOOR LAMP

CB2

This page lists the contents included in the box. Please take time to identify the hardware as well as the individual components of the product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage. Please follow the assembly instructions closely. Improper assembly can result in personal or property damage.



cleaning & care

Dust surfaces with a dry soft cloth. Do not use cleaners or polishes on the lamp.

1

A. Fit threaded stud of **lamp assembly** into **base assembly**.
B. Attach from below with 1 **hex nut** and **washer** and secure with a **hex wrench**.



hardware & components

800.606.6387

1 - hex nut

1 - washer

1 - hex wrench

1 - 13 watt max CFL bulb (INCLUDED)
OR
1 - 60 watt max type A standard bulb (NOT INCLUDED)

important safety instructions

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to override this safety feature.

2

Insert 1 **bulb** into socket. DO NOT EXCEED SPECIFIED WATTAGE.
Assembly is complete.