


Thank you for purchasing the **Cage Wall Sconce**. This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

For safe mounting, it is essential to use wall anchors appropriate to your wall type (i.e. plaster, drywall, concrete, etc.). Mount to wood studs whenever possible. **These instructions are for drywall mounting only.**

hardware



2 - wall anchors



2 - screws

Missing hardware?

Please call **800.606.6387** for replacements.


tools required



power drill
(for pilot holes only)



level



Phillips head screwdriver

components



1 - sconce assembly



1 - wall bracket




1 - 13 watt max CFL bulb (INCLUDED)
OR 60 watt max type A standard bulb (NOT INCLUDED)


cleaning & care

Dust surfaces with a dry, soft cloth. Clean shade with a glass cleaner.

NOTE: If you are unsure about your wall type or what mounting method you should use, consult a qualified professional or your local hardware store.



- 1 A) Determine the location for the wall sconce. Using a **level**, position **wall bracket** and mark 2 hole positions on the wall. Set bracket aside.
- B) Drill a pilot hole in the wall stud. If the wall stud is not available, drill a hole in the wall that is slightly smaller in diameter than the anchor.
- C) Insert 2 **wall anchors** into holes. Using a **Phillips head screwdriver**, tighten each anchor until the flange of the anchor is flush.
- D) Insert 2 **screws** through wall bracket and into corresponding anchors in the wall. Secure, but do not overtighten screws with a **Phillips head screwdriver**.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to override this safety feature.

- 2 A) Fit **sconce assembly** onto the wall bracket as shown. Make sure the assembly securely engages and is supported by wall bracket.
 - B) Insert 1- **bulb (included)** into socket. **DO NOT EXCEED SPECIFIED WATTAGE.**
- Installation is now complete.